

Corn Field Crappie Gear 360 Mount for Terrova Trolling Motor

Mount large bracket to the tapered housing of the trolling motor above where it locks into the deploy position.

Slide 360 shaft and wires thru the tube with the black clamp ending up next to the 360 head.

Tighten the clamp around the tube securing the tube to the 360 shaft.

Slide 360 and the tube thru the mounted bracket.

Using the long clamp. Clamp around the tube and the trolling motor shaft with the split bushing going around the trolling motor shaft.

Use the two split collars one on each side of the long clamp to set the height of the 360 on the trolling motor. Tighten both split collars.

Last tighten both set screws on each side of the large bracket. Snug them up into the tapered housing. DO NOT over tighten.

Thank you for the purchase of the best most secure 360 to trolling motor bracket available.

Check out are other quality fishing accessories at www.cornfieldcrappiegear.com

MADE IN THE USA